

Echo

WALL LIGHT





Class I 220–240V ~ 50/60Hz Power 12 | 20 Watts IP Rating

Material Aluminium Warranty 3 Years









① CAUTION - Must Be Installed By A Licensed Electrician

Please read instruction manual on **both** sides carefully before installing luminaire.


- Please read instructions for installation of luminaire provided below.
 Safety of this luminaire and warranty will be voided unless followed.
- Installation and operation of this luminaire must be within
 accordance with national safety regulations. Unios™ does not warrant
 any liability when damage is caused by misuse or improper installation.
- This luminaire is void of warranty if any part has been modified.
 Please visit unios.com/warranty for more information.
- Over-voltage protection units should be installed to prevent electronic control gear from failing due to electrical spikes, e.g. from switching of inductive loads





Mounting Plate

The gasket supplied with the wall bracket **must** be used during electrical installation to ensure no water ingress through the back of the fitting. It is strongly advised to also use a sealant to ensure a full seal around the cable entry and mounting holes.



Model	Α	В	С	D
Echo 600 (12W)	98.5	33.5	70	15
Echo 900 (20W)	123.5	38	90	19

Installation Instructions

- Must be installed by a licensed electrician.
- **2** Before installing, make sure the power supply is switched off.
- Follow the steps in the figure shown for installation:

 Note: Installation requires 30mm space above and below luminaire
 - A. Drill mounting holes and pull wires through mounting plate.
 - B. Fix the mounting plate onto the wall with screws.
 - C. Use supplied heat shrink solder joiners to terminate mains power to electronic control gear.
 - D. Fix the luminaire onto the mounting bracket with screws.

Note: After completing above steps, ensure the luminaire is firmly fixed to the mounting plate. The luminaire must be cleaned following these installation instructions. Termination of wiring and installation of the product shall be conducted such that the luminaire's stated IP rating is not affected.

universal light

Edition 3.8.17 | Product design and technical data may be subject to change





Accessories (Included)









2x Wall Screws




1x Allen Key



3x Heatshrink Solder Joiners

Wiring

This luminaire must be installed in conjunction with electronic control gear (Built-in).



Dimming

This luminaire can not be dimmed. Specific DALI option available.

Cleaning

Before cleaning, disconnect from mains supply and allow luminaire to cool.


Regular cleaning of the luminaire is strongly recommended. In harsher conditions, it is recommended that a strict cleaning schedule is in place to ensure no eroding chemicals are left on the surface for long periods. To clean luminaire, only use a damp, microfibre cloth. A dilute solution of a mild pH-neutral liquid detergent can be used for resistant dirt (Solvents must not be used). Please note surface of luminaire must be wiped down with a clean damp microfibre cloth to ensure no residue is left on the surface. Take care not to damage the surface of the luminaire. Do not use high pressure cleaners.

Cleaning of Luminaire Lens

The luminaire lens or glass can be cleaned with glass specific cleaning agents that are ph-neutral, alcohol-free and non-abrasive. Always use a damp microfibre cloth and take care not to damage any seals surrounding the glass.



Class I





Protected against dust completely and Jets of water from all directions.



220-240V 50-60hz AC Supply.



Indoor Use

This luminaire is suitable for indoor use only.

universal light

Edition 3.8.17 | Product design and technical data may be subject to change

